

Radios – Selecting the VR/DVR Channel

The VR Channels will only be displayed for the selected network. You will not see DVR01 unless you set the radio head (Main Radio) to the LMRN and DVR system. Likewise, you will not see VR01 until you have set the radio head to the Fleetnet Channel and VR system.

Changing from Fleetnet to LMRN (Old system to New system)

When the Mobile Head is on (LMRN) LON City 1:

1. Press and hold the “P” button for 3 seconds to open the menu
2. Using the Channel Knob, select the DVR01
3. Press the “Sel” Menu button
4. Press the “P” button as normal to turn the repeater on and off.

To Switch the Portable to the LMRN – DVR01:

1. Ensure that the radio head is set to (LMRN) LON CITY 1
2. Remove the portable radio from its case, as you will need to see the screen and access the buttons
3. Push the single green dot button “Zone”
4. Scroll to LMRN DVR and push “Sel”

Changing from LMRN to Fleetnet (New System to Old System - Going into an area that has not transitioned)

When the Mobile Head is on (AD Fleetnet) AD – LDN City 1:

1. Press and hold the “P” button for 3 seconds to open the menu
2. Using the Channel Knob, select the VR01
3. Press the “Sel” Menu button
4. Press the “P” button as normal to turn the repeater on and off.

To Switch the Portable to the AD – London – VR03:

1. Ensure that the radio is set to AD – LDN City 1
2. Remove the portable radio from its case, as you will need to see the screen and access the buttons
3. Push the single green dot button “Zone”
4. Scroll to FN VR and push “Sel”